

Improve the work safety on high pressure tube flanges

On high pressure equipment very often there is not enough place to use standard tooling. This is the reason why it is difficult for the workers to work safe and reach the right preload.

By changing the standard Hexnut to the 12PT-Nut the standard tooling can be used and so the bolts can be tighten in a safe way to the required preload.